


WALLCLAW[®] LOC-N-LOAD

HOW IT WORKS




FRONT OF WALL



INSERT SCREW


WallClaw Clamps
To Back of Wall

BACK OF WALL



Screw activates CAM
Leg rotates UP behind wall
WallClaw clamps to wall & locks in place

WallClaw Anchor




SIDE VIEW

TOP VIEW

WallClaw side view has
a knife blade profile

WallClaw top view has
flat bearing plate for
greater load
distribution
(Dashed Lines)

WallClaw Anchor



WallClaw rotates MORE
than 90 degrees

WallClaw stops on the
back of the wall

Strong back pressure
CLAMPS WallClaw to
wall

WallClaw Anchor



Small Slit in Wall AFTER
removal of WallClaw

EASY REPAIR

WallClaw Anchor